JSSB717 Red Dot Sight OPERATING INSTRUCTIONS


IMPORTANT This manual contains important information about your red dot sight. This manual should always accompany the red dot sight in case ownership should change. Always follow firearm safety rules as outlined by the firearm's manufacturer. Keep this red dot sight and all firearm related products secured and away from children or other unauthorized users.

WARNING Do not look at the sun through a red dot sight as it may cause permanent damage to your eye and/or vision.

WARNING Before installing or removing your JTS red dot sight, remove the magazine from the firearm. Then visually check that the chamber and action are clear of ammunition.

GUN HANDLING PROCEDURES

- Always follow safe gun handling procedures.
- Always keep muzzle pointed in a safe direction.
- · Gun should be unloaded when not in use.
- · Be sure of your target and what is beyond it.
- · Always wear eye and ear protection when shooting.
- Familiarize yourself with the gun you are using.
- 1. Objective lens
- 2. Brightness adjustment button (up)
- 3. Brightness adjustment button (down)
- 4. Windage adjustment
- 5. Elevation adjustment
- 6. Locking bolt
- 7. Battery compartment



ACAUTION

Before mounting your JTS red dot sight, be sure to read carefully the operating instructions of the sight. Be sure that your gun is not loaded and the gun safety switch is in the "SAFE" position before you attempt to install your red dot sight.

QUICK START

- Power On: With a battery installed, press the brightness adjustment button (2). This will turn on the sight to the last, used level of intensity.
- Power Off: To turn off the sight, press and hold the brightness adjustment button (2 or 3) for three seconds.

FEATURES AND SPECIFICATIONS

- Brightness: The JTS JSSB717 red dot sight is adjustable for 8 levels of brightness. Pressing the (2) button will increase the brightness a single step until the maximum level has been reached. Pressing the (3) will decrease the reticle brightness until the minimum level has been achieved. The last two settings are ultra-low for use with NV equipment.
- Auto Off: Your JTS red dot sight is equipped with an intelligent power save feature to

prolong the life of your battery when not in use. After 1 hour without adjustment, the sight will transfer to sleep. Upon any movement of the optic, the system powers up the LED to the last known setting. The motion sensor will not reactivate the sight if it has been turned off manually.

• Battery: Your JTS red dot sight is powered by one **AAA** alkaline battery. Battery life may vary, depending on reticle intensity, environmental conditions and use.

WARNING Confirm that your red dot sight is securely and properly installed. An improperly installed sight could become detached during recoil causing injury.

MOUNTING THE RED DOT SIGHT

Your JTS red dot sight has an integrated mounting rail at the bottom of the sight with a locking bolt. The sight mounts onto a Picatinny rail or weaver scope base. Loosen the locking bolt (6) using the included slotted screwdriver. Slide the sight onto the scope rail with objective lens pointing toward muzzle end and move the sight back and forth to adjust for desired placement. Be sure that the shaft of locking bolt fits into the groove on the rail and rests against the front (muzzle end) side of the groove. Always leave sufficient clearance (min. 4 inches) between your eye and the eyepiece end of the sight. Tighten the locking bolt to securely hold the sight in place.

ACAUTION

Since zeroing involves actual shooting of live rounds, it should be done at an approved shooting range or equally safe area. Be sure to use eye and ear protection when shooting.

ZEROING, WINDAGE AND ELEVATION ADJUSTMENTS

Your JTS dot sight is fully adjustable for both windage and elevation. The red dot sight comes from the factory with the red dot centered. When your Picatinny or weaver rail is properly aligned, you normally only need to make small adjustments to fully have the sight zeroed.

Use a screw driver or coin to adjust point of impact by turning the screw in the direction as needed. Each click of the adjustment screw moves the dot by 1" at 100 yards.

ELEVATION ADJUSTMENT			WINDAGE ADJUSTMENT				
Down*	Clockwise		Left*	Clockwise		bact	
Up*	Counter- Clockwise		Right*	Counter- Clockwise		*Point of Impact	
6							

WARNING Keep batteries away from children. There is a chemical burn hazard associated with batteries. If a new or used always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

REVIEWING BATTERY SAFETY

- When used correctly, batteries provide a safe and dependable source of portable power. However, misuse or abuse may result in leakage, fire, or explosion.
- Batteries can explode or leak and cause burns if installed backwards, disassembled, charged, or exposed to water, fire or high temperature.
- Always install your batteries correctly, observing the "+" and "-" marks on the battery and the device.
- Always replace the whole set of batteries at one time. Do not to mix old and new batteries, or batteries of different types.
- Store unused batteries in their original packaging and away from metal objects that may short-circuit them.

- Remove discharged batteries from equipment promptly to avoid possible damage from leakage.
- The batteries are supplied in a charged state, and are not designed for recharging. Recharging may cause leakage, fire, or explosion.

REPLACING THE BATTERY

Your JTS red dot sight uses one AAA Alkaline battery. Unscrew counter-clockwise to open the battery cover, insert new battery with positive (+) end pointing inside, replace and tighten the cover. Check and see if the unit powers up by pushing once on the power switch. Always remember to carry a spare battery with the sight.

NOTICE Always remember to turn off the power when the optic is not in use.

NOTE: Batteries must not be put in the household waste. Dispose of them properly, hand them in at your local shop for disposal or take them to a used battery collection location. Please recycle used batteries.



MAINTENANCE

When not in use, your JTS red dot sight should be kept in a clean, dry and ventilated place away from any corrosive material with lens covers on. Never try to take the red dot sight apart or clean it internally. Lens surfaces may be cleaned with bursts of air, a lens brush, or the included microfiber cloth. Your JTS red dot sight requires minimal maintenance. If your sight should fail to power up, remove and replace the battery.

SERVICE

Do not return defective or damaged product to the dealer. If your optic needs repair, call JTS (281) 647-9130 and ask for the Service Department or visit www.jtsgroup.us. DO NOT ATTEMPT TO DISASSEMBLE IT! Your red dot sight requires special tools and fixtures to repair it. Any disassembly or modification not performed by JTS will void the warranty.

DO NOT RÉTURN THIS PRODUCT TO THE STORE: If you have any questions or concerns about JTS Group, Inc. products, please contact us at (281) 647-9130 or visit www.jtsgroup.us and one of our service techs will be glad to assist you.

LIMITED LIFETIME WARRANTY

This product is warranted to the retail consumer for the life of the optic against defects in material and workmanship and is not transferable.

WHAT IS COVERED: Replacement parts and labor.

WHAT IS NOT COVERED: Shipping charges to JTS Group for defective product and damages caused by abuse or failure to perform normal maintenance as well as any other expense. Consequential damages, or incidental expenses, including damage to property. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. **WARRANTY CLAIMS:**

If your JTS product is found to have defects in materials or workmanship, we will repair or replace it free of charge for the lifetime of the product. This warranty does not apply to owner neglect or abuse of the product. Simply ship your scope to the address below with an enclosed note indicating the problem you are having as well as your contact information.

JTS Group, Inc. 7724 Cherokee St Katy, TX 77494 Phone: (281) 647-9130

IMPLIED WARRANTIES: Any implied warranties, including the implied warranties of merchantability and fitness for a particular purpose, are limited in duration to the life of the optic. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. TO THE EXTENT ANY PROVISION OF THIS WARRANTY IS PROHIBITED BY FEDERAL, STATE, OR MUNICIPAL LAW; WHICH CANNOT BE PREEMPTED, IT SHALL NOT BE APPLICABLE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE AND COUNTRY TO COUNTRY.

SPECIFICATIONS	JSSB717		
Reticle Type	Unit Spot		
Color / Dot Size	Red / 2 MOA		
Reticle Brightness	1-8 and OFF		
Magnification	1x		
Eye Relief	Unlimited		
Elevation/Windage Adjustment	±30 MOA		
Finish	Black Anodized Aluminum		
Mount	Weaver / Picatinny		
Click Value	1 Click = 1 MOA		
Objective Size	20 mm		
Length	75 mm / 2.95 in.		
Weight	150 g / 5.29 oz		



We reserve the right to make design changes, color changes and technical improvements. No responsibility is accepted for printing errors or incorrect information.

> Distributed by JTS Group, Inc. 7724 Cherokee St Katy, TX 77494 www.jtsgroup.us

© 2020 JTS America 04.20