

SWATFORCE

QUICK AIM ELECTRONIC

RED/GREEN DOT



CAUTION: Be sure that the firearm is not loaded. Practice safe firearm handling procedures at all times.

1 Component Chart

- 1 Flip Open Lens Covers
- 2 Red/Green Dot On/Off Switch and Brightness Adjustment
- 3 Battery Compartment
- 4 Elevation Adjustment
- 5 Windage Adjustment
- 6 Mounting Deck & Lock-Nuts



2 Installing/Replacing Battery

Lithium Battery

Duracell / Sunrise / Radio Shack
DL2032 / Cr2032 / 5004L

- 1) Remove the Battery Compartment lid with a coin.
- 2) Insert the battery into the battery housing with the positive pole (+) facing up.
- 3) Screw the Battery Compartment lid back in place.



3 Mounting Red/Green Dot Scope

- 1) Place the mounting deck onto the rail.
- 2) Adjust the mounting deck position until you are satisfied with the eye relief.
- 3) Tighten each lock-nut with a screwdriver or coin.



CAUTION: Always adhere to the rules for the correct and proper handling of guns. Always select an adequate and safe backstop and always wear protective shooting glasses.

4 On/Off Switch and Brightness Adjustment

- 1) The white dot on the left side of the sight indicates the “Current Setting”.
- 2) When the Current Setting is “R” or “G”, the unit is off.
- 3) Red/Green colored coded numbers indicate the brightness of the illumination.
- 4) Select the color illumination and adjust to the desired brightness.
- 5) To conserve battery life, always turn off when not in use.



5 Sight Adjustments

- 1) Turn on the illumination and set to the desired brightness.
- 2) Place a target 100 yards away (25 yards for airgun scopes).
- 3) Use a sturdy bipod or shooting stand, aim the dot at the center of the target and fire a shot, if safe to do so.
- 4) If the impact point is exactly at the center of the target then the dot is zeroed. If it is not, adjust windage or elevation in the direction of bullet impact. For example:
 - a. Each click is equal to approximately $\frac{1}{4}$ inch at 100 yards.
 - b. If your shot is 1" higher at 100 yards, turn the elevation adjustment in the “up arrow” direction 4 clicks.
 - c. Use the technique for both windage and elevation adjustments.
- 5) Having adjusted the windage and elevation as required, fire another test shot. Keep adjusting and test firing until the test shot impacts on the center of the target when the dot is on the center of the target.

6 Care and Cleaning

The sight body and the mounting deck may be cleaned with a soft, clean cloth dampened with some weapon oil. Lenses can be cleaned with a soft lens brush, and a lens cleaning cloth.